# Installation Instructions



**SMETM** 

AESSEAL Marine plc, Unit 4 Venlo Industrial Estate, Knowles Street, Bradford, West Yorkshire, BD4 6HA, UK


Tel: +44 (0) 1274 720775 Fax: +44 (0) 1274 729022
Email: seals@first4seals.com - Web: www.first4seals.com
Copyright © 2019 AESSEAL Marine plc - Reference Issue • 2INST-SME-05




## **WARNING**

Extreme care must be taken to ensure safe operation of equipment. If in doubt seek expert advice. For Technical Support: Email: technical@first4seals.com Telephone: +44 (0)1274 720775.







| ITEM | DESCRIPTION      |
|------|------------------|
| 1    | CLAMP RING       |
| 2    | DRIVE SCREW      |
| 3    | SPRING           |
| 4    | O-RING           |
| 5    | ROTARY FACE ASSY |

| IMPERIAL SHAFT SIZE (d1) | WORKING LENGTH |
|--------------------------|----------------|
| 1.000" - 2.500"          | 1.122"         |
| 2.625" – 4.000"          | 1.378"         |

| METRIC SHAFT SIZE (d1) | WORKING LENGTH |
|------------------------|----------------|
| 25mm – 63mm            | 28.5mm         |
| 65mm – 100mm           | 35.0mm         |

### **Pre-Installation:**

- ✓Check shaft diameter (d1) is in tolerance: Imperial Shafts +/- 0.002" Metric Shafts +0/ -0.05mm
- √Check shaft run out is in tolerance: < 0.005" (0.13mm).
- √Check shaft end float is in tolerance: <0.005" (0.13mm).
  </p>
- √Check shaft (ref. A) for sharp edges to ensure no damage to secondary seal during installation.

# Installation:

- ✓Ensure seal parts are kept as clean as possible and protected from damage.
- ✓Disassemble equipment to allow seal location on shaft.
- ✓Apply suitable lubricant to shaft.
- √Position seal on shaft.
- ✓Re-assemble equipment into operational position.
- ✓Position gland follower, including the stationary face, on to stuffing box face ensuring concentricity to shaft and fully tighten.
- ✓Slide seal in to position against the stationary face.
- √Tighten ALL fixing screws onto shaft equally (ref. B).
- √Check for shaft binding or rubbing by rotating the shaft slowly by hand.
- √If fouling occurs, remove the seal, check shaft and start installation again.
- √If problem persists contact first4seals.
- ✓Ensure pump is primed before operation.

### **DECLARATION OF INCORPORATION**

This mechanical seal must not be put into service until the relevant machinery into which it is incorporated has been declared to be in conformity with the provisions of the Machinery Directive.